

USER GUIDE

SIDIZ

T55

Better seat,
Better life.

SIDIZ T55를

구입해주셔서 감사합니다.

한국어로 사용자 매뉴얼을 보려면
4페이지로 이동하십시오.


Thank you for

buying the SIDIZ T55.

To read your manual in
English go to page 12.


조절 기능

※ 구매한 사양에 따라 일부 기능은 제한될 수 있습니다.



5P 좌판
높이, 깊이 조절

8P 팔걸이
높이, 좌우,
앞뒤 조절



7P 머리 받침대
높이, 각도 조절



9P 등판
각도, 강도 조절

11P 요추지지대
자동 조절

1 좌판

높이 조절 오른쪽 손잡이를 들어 올린 상태로 좌판에 실리는 무게를 조절해 높이를 조절하세요. 손잡이에서 손을 떼면 높이가 고정됩니다.



TIP 무릎 각도가 90°가 될 수 있도록 조절해 주세요.



1 좌판

깊이 조절 오른쪽 좌판 아래 손잡이를 잡고 바깥으로 당긴 상태로, 좌판을 앞뒤로 밀고 당기세요.

TIP 앉았을 때 좌판 끝과 오금 사이에 5cm 간격이 있도록 조절해주세요.




2 머리 받침대


* 머리 받침대 (H) 포함 사양에 한함.

높이 조절 머리 받침대를 두 손으로 잡고 위아래로 밀어 조절합니다.

- ① 강한 힘으로 머리받침대를 올릴 경우 빠질 수 있으므로 적절한 힘으로 조금씩 조절하세요.




각도 조절 머리 받침대의 앞뒤를 밀면 위아래로 회전합니다.




3 팔걸이

높이 조절 팔걸이 바깥쪽 하단에 위치한 버튼을 누른 상태로, 위아래로 조절하세요.





좌우, 앞뒤 조절 팔걸이 패드를 잡고 좌우 또는 앞뒤로 미세요.



4 등판 젖힘

각도 조절 조절 전, 왼쪽 손잡이가 아래로 내려가 있는지 확인합니다. 원하는 각도 만큼 등판에 기대면 후, 왼쪽 손잡이를 위로 올립니다.

TIP 등판이 움직이는 최대 각도를 5단계로 설정 가능합니다.





4 등판 젖힘

강도 조절 손잡이를 바깥으로 뽑아낸 뒤 회전하여 원하는 강도로 세기를 조절해주세요.



- 강하게 : 좌판 앞방향으로 회전
- 약하게 : 등판 방향으로 회전

❗ 등판에 기댄 상태로 조절하지 마세요.





5 요추지지대

자동 조절 요추지지대가 사용자의 움직임에 따라 반응하여 별도 조작이 필요 없습니다. 등판에 기댈 때 등판이 외부 프레임의 레일을 따라 슬라이딩되며 허리에 밀착됩니다.



ADJUSTMENT FEATURES



※ Some Features may not be included, depending on your purchase.



1 SEAT

Height Pull the lever up on the right side and control the weight on the chair. Release it at the desired height.



TIP Check that the knee angle is 90°.



1 SEAT

Depth Pull out the lever on your lower right side of the seat, and hold it out as you push the seat forward or back.

TIP Spare 5 to 7 centimeters between the seat edge and the back of your knees.




2 HEADREST


* Options with Headrest (H) only.

Height Grab the headrest using both hands, and fix it at the desired height.

- ① Adjust the height of the headrest little by little with the proper force as it may come out.




Angle Push the headrest back and forth, then it will rotate up and down.




3 ARMREST

Height Push the button outside of each arm pad, and adjust the height of armrest.





Angle, Depth Grab the arm pad and move it in/out or back/forth.



4 BACKREST TILTING

Angle Before adjusting, make sure that the lever on the left side is pushed down. Lean to the angle you want, and pull the lever upwards. The chair will be tilted only to that angle.

* Set the maximum tilting angle to 5 steps





4 BACKREST TILTING

Tension Pull out the right handle and rotate it to set the proper tension.

- For stronger tension : forward
- For weaker tension : backward



⚠ Do not adjust while leaning against the backrest.



5 LUMBAR SUPPORT

Auto- matic

The lumbar support responds to user movement and does not require adjustment. The backrest slides along the rails of the outer frame, and naturally fits to the user's back and waist.



SIDIZ

VER. 0

www.sidiz.com